

Havahart®

Caring Control for Pets and Wildlife®

Extra Dog Collar Receiver



OPERATING INSTRUCTIONS

**Model
#5145G**

Safety Precautions

All Havahart products have been thoroughly tested for safety and effectiveness. To protect your dog and yourself, please observe the following safety precautions:

- Never leave the collar on your dog for more than 12 hours at one time.
- Only use the Havahart Fence Free System on healthy dogs ages 6 months and older, and weighing more than 8 lbs. Consult your veterinarian before using the collar if your dog has health problems.
- Check collar fit each time you place collar on your dog – the collar must be fitted properly to work effectively (see “Fitting the Collar”).
- Check dogs daily for skin irritation and do not use the collar if the skin is irritated.
- Always use the lowest stimulation possible to train your dog.

Contents of the Havahart Extra Collar

1. Water Resistant SMART Collar Receiver with black nylon collar. Powered by a disposable CR2450 coin lithium battery.
2. Stimulation Probes (2) sets: (2) short probes for short-haired dogs and (2) long probes (factory installed) for dogs with longer or thicker coats. The short probes are supplied separately in this carton.
3. Heart-Shaped Tester

GETTING STARTED

Installing the Battery

Before you begin, install the CR2450 lithium battery (included) in the collar. Install by removing the battery hatch cover, installing the battery with the plus (+) side facing out and replacing the battery hatch cover.

The battery life will depend on how frequently your dog receives the static correction. If your dog is sleeping or inactive, the collar will go into sleep mode

Congratulations on your purchase. The Havahart® Extra Dog Collar Receiver will allow an additional dog to be contained in your Fence Free Containment System.

Havahart is committed to caring control of pets and wildlife, and all of our products are designed to enhance the relationship between animals and people. Through effective use of Havahart canine products, our goal is to help strengthen the bond between dogs and their owners.

(power saving mode) until the tilt vibration sensor (collar movement) wakes it up. This smart collar function dramatically enhances battery life. The collar will wake up instantly when it detects any motion.

You'll know the collar batteries need to be replaced when you see the collar indicator light blink red every 10 seconds.

Installing the Probes

Your collar comes factory installed with long probes for thick or long-haired breeds. You can use the short probes for short-haired dogs. To change the probes, unscrew the long probes and replace them. Be sure the rubber insulator is between the probe and the collar strap. Hand-tighten the probes as far as you can. Do not over tighten.

Always use rubber insulators to keep probes tight and provide insulation during damp conditions. The rubber insulators are necessary to maintain the water resistance.

Fitting the Collar

Very Important! The collar must be fitted properly to work effectively. Be sure the collar is turned off. Position the collar high up on your pet's neck underneath the chin, with the probes facing upward touching the pet's skin. Make sure probes maintain contact with skin. Adjust nylon collar to fit snug but not tight. You should be able to slide one finger between your pet's coat and the training collar. ***The correct fit is essential because most training failures are caused by probes not making direct contact with the skin.***

Once collar is adjusted to correct length, remove collar, trim excess, and use a match or lighter to carefully melt the end of the strap to prevent fraying. Remember, for growing dogs, check collar size weekly and adjust when necessary. Allow enough nylon for the collar to grow with your dog.

Havahart recommends that you help your dog get used to wearing the collar before you turn it on for training. Let your dog wear it continuously for a minimum of two separate 12-hour sessions (over the course of 2 days). This adjustment period will deliver better learning, as your dog will not become collar-wise, that is, only obeying when wearing the collar.

IMPORTANT: Never leave collar on the dog for more than 12 consecutive hours.

Turning Collar On & Off:

To turn collar on, push the On/Off button and hold it for 2 seconds. A green LED light will appear, and the collar will buzz. Release the button – your collar is now ready to go.

Immediately after the collar turns on the light will blink. The number of blinks will correspond to the static stimulus setting level. One blink means it is set at Level 1 - Tone Only, two blinks means Level 2 , three blinks means Level 3, etc.

Note: If your dog is sleeping or inactive, the collar will go into sleep mode (power saving mode) until the tilt vibration sensor (collar movement) wakes it up.

To turn the collar off, push the On/Off button and hold it for 2 seconds. A red LED light will appear, and the collar will buzz. Release the button and the collar will be turned off.

Changing the Collar Correction Level

The collar comes preset at Level 2. Always start with this level and check your dog's response to the static stimulus. Always use the lowest level necessary to get the desired response.

To check the current stimulation level, begin with the collar turned on. Then push the On/Off button for one second and release it. The number of blinks will correspond to the static stimulus level. One blink means it is set at Level 1- Tone Only, two blinks means it is set to Level 2, etc.

The correction setting can easily be changed, one level at a time, once the collar is powered on. Simply press the button once to increase the correction level by 1 setting. For example, the collar is set at Level 1 and you wish to increase it to Level 2 – press the button once and wait for two blinks. To increase to Level 3, press one more time, wait for three blinks, etc. up to Level 6.

Collar Static Stimulus Level

1 blink – Level 1 Tone Only

2 blinks – Level 2 Low stimulation

3 blinks – Level 3 Low-Med. stimulation

4 blinks – Level 4 Medium stimulation

5 blinks – Level 5 Med.-High stimulation

6 blinks – Level 6 High stimulation

Once you set the stimulation level, the collar will remain at that level until you change it...even if you turn the collar off.

TROUBLESHOOTING

We are committed to assisting you with the use of our products. If you have any questions or concerns, contact Woodstream Customer Care at 1-800-800-1819, option 1.

LIMITED WARRANTY

See www.havahartwireless.com for Limited Warranty information.
Rev 1111

For more information go to: www.havahartwireless.com or call 1-800-800-1819, option 1.